

Nanodrop Instructions

For how to use please follow this link for the manual:



Do not use wet gloves.

Be careful not to slam down the head as it can break the pedestal.

If there is not adequate surface tension on the pedestal, you will need to use the reconditioning kit prior to measuring samples (see manual for instructions).